



Operating manual



IPPeco

Peltier cooled incubator IPPeco

About this manual

Purpose and target audience

This manual describes the construction, function, transport operation and maintenance of cooled incubators IPPeco. It is intended for use by trained personnel of the owner, who have the task of operating and/or maintaining the respective appliance. If you are asked to work on the appliance, read this manual carefully before starting. Familiarise yourself with the safety regulations. Only perform work that is described in this manual. If there is something you do not understand, or certain information is missing, ask your manager or contact the manufacturer. Do not do anything without authorisation.

Versions

The appliances are available in different configurations and sizes. If specific equipment features or functions are available only for certain configurations, this is indicated at the relevant points in this manual. The functions described in this manual refer to the latest firmware version. Due to individual configurations and sizes, illustrations in this manual may be slightly different to the actual appearance. Function and operation are identical.

Other documents to be observed:

- For operation of the appliance with MEMMERT AtmoCONTROL, observe the separate software manual. To open the AtmoCONTROL software manual, click on "Help" in the AtmoCONTROL menu bar.
- For service and repair work, observe the separate service manual

Storage and resale

This operating manual belongs with the appliance and should always be stored where persons working on the appliance have access to it. It is the owner's responsibility to ensure that persons who are working on or are going to work on the appliance know where to find the operating manual. We recommend that it is always stored in a protected location close to the appliance. Make sure that the operating manual is not damaged by heat or humidity. If the appliance is resold or transported and then set up again at a different location, the operating manual must remain with it. The current version of this operating manual in PDF format is also available for download from **www.memmert.com/de/downloads/**

Manufacturer address and customer service

MEMMERT GmbH + Co. KG
Willi-Memmert-Str. 90-96
91186 Büchenbach
Germany

Phone: +49 (0)9122 925-0
Fax: +49 (0)9122 14585
E-mail: sales@memmert.com
Internet: www.memmert.com

Customer service:
Hotline: +49 (0)9171 9792 911
Service fax: +49 (0)9171 9792 979
Email: service@memmert.com

For service enquiries, please always specify the appliance number given on the type plate.

Content

1. Safety	5
1.1 Terms and signs used.....	5
1.2 Product safety and dangers.....	6
1.3 Requirements of the operating personnel	7
1.4 Responsibility of the owner	7
1.5 Intended use	7
1.6 Changes and alterations	8
1.7 Behaviour in case of malfunctions and irregularities	8
1.8 Switching off the appliance in an emergency.....	8
2. Construction and description	9
2.1 Design	9
2.2 Description	10
2.3 Material	10
2.4 Electrical equipment	10
2.5 Connections and interfaces	11
2.6 Designation (nameplate).....	11
2.7 Technical data.....	12
2.8 Applied directives and standards	13
2.9 Ambient conditions.....	13
2.10 Scope of delivery.....	13
3. Delivery, Transport and Setting Up	14
3.1 Safety	14
3.2 Delivery.....	14
3.3 Transport.....	14
3.4 Unpacking	15
3.5 Disposing of packaging material	15
3.6 Storage after delivery	15
3.7 Setting up.....	16
3.8 Installation options	17
3.9 Level and secure the device against rolling away (Sizes 1400 and 2200)	18
3.10 Tilt protection.....	19
3.11 Adjusting doors	19
4. Putting into operation	20
4.1 Connecting the appliance	20
4.2 Switching on.....	21
5. Operation and control	22
5.1 Operating personnel.....	22
5.2 Operating the appliance	23
5.3 Operating modes.....	25
5.4 Monitoring function.....	27
5.5 Ending operation	27

6. Malfunctions, warning and error messages	28
6.1 Warning message of the monitoring function	28
6.2 Power failure	29
7. Menu mode	30
7.1 Overview	30
7.2 Basic operation in menu mode using the example of language selection	31
7.3 Setup	32
7.4 Date and Time	35
7.5 Calibration	36
8. Maintenance and Servicing	38
8.1 Cleaning	38
8.2 Decontamination	39
8.3 Regular maintenance	39
8.4 Repairs and service	39
9. Storage and disposal	40
9.1 Storage	40
9.2 Disposal	40

1. Safety

1.1 Terms and signs used

In this manual and on the appliance itself, certain common terms and signs are used to warn you of possible dangers or to give you hints that are important in avoiding injury or damage. Observe and follow these notes and regulations to avoid accidents and damage. These terms and signs are explained below.

1.1.1 Terms used

	Warns of a dangerous situation that leads directly to death or serious (irreversible) injuries.
	Warns of a dangerous situation that might lead to death or serious injuries.
	Warns of a dangerous situation that might lead to moderate or minor injuries.
	Warns of material damage

1.1.2 Signs used

Symbol	Meaning	Symbol	Meaning
	General warning sign - observe operating instructions		Gases / vapours
	Caution - current		Prohibited - do not wear
	Warning - flammable substances		Prohibited - do not enter
	Caution - hot surfaces		Prohibited - do not tip
	Danger of explosion		Note - disconnect the mains plug
	Observe information in separate manual		Note - wear gloves

Symbol	Meaning	Symbol	Meaning
	Note - wear safety shoes		Note - observe number of people

1.2 Product safety and dangers

The appliances described in this manual are technically sophisticated, manufactured using high-quality materials and subject to many hours of testing in the factory. They reflect the state of the art and comply with recognised technical safety regulations. However, there are still risks involved, even when the appliances are used as intended. These are described below.

DANGER



Danger due to electric shock.

Penetration of liquid into the appliance can cause electric shocks and short circuits.

- Protect the appliance from splashing water.
- Switch off the appliance and disconnect the mains plug before cleaning and maintenance work.
- The appliance must not be cleaned and disinfected wet. Allow the appliance to dry completely before putting it back into operation.

WARNING



Leaving the door open during operation can cause the appliance to overheat or pose a fire hazard. Do not leave the door open during operation.

WARNING



When loading the appliance with an unsuitable load, poisonous or explosive vapours or gases may be produced. This could cause the appliance to explode, and persons could be severely injured or poisoned. The appliance may only be loaded with materials / test objects that do not emit any poisonous or explosive vapours when heated up.

WARNING



With appliances above a specific size, you could become accidentally locked inside, which could put you at risk of death. Do not climb into the appliance!

WARNUNG



When removing heated the load from the unit, it may fall and cause fire hazards. Do not place the unit on a surface made of flammable material.

⚠ CAUTION

Depending on operation, the surfaces in the interior of the appliance and the chamber load may still be very hot after the appliance is switched off. Touching these surfaces can cause burns. Wear heat-resistant protective gloves or wait until the appliance cools down after switching off before touching.

1.3 Requirements of the operating personnel

The appliance may only be operated and maintained by persons who are of legal age and have been instructed accordingly. Personnel who are to be trained, instructed or who are undergoing general training may only work with the appliance under the continuous supervision of an experienced person. Repairs may only be performed by qualified electricians. The regulations in the separate service manual must be observed.

1.4 Responsibility of the owner

The owner of the appliance

- is responsible for the flawless condition of the appliance and for it being operated in accordance with its intended use
- is responsible for ensuring that persons who are to operate or service the appliance are qualified to do this, have been instructed accordingly and are familiar with the operating instructions at hand
- must know about the applicable guidelines, requirements and operational safety regulations, and train staff accordingly
- is responsible for ensuring that unauthorised persons have no access to the appliance
- is responsible for ensuring that the maintenance plan is adhered to and that maintenance work is properly carried out
- has to ensure that the appliance and its surroundings are kept clean and tidy, for example through corresponding instructions and inspections
- is responsible for ensuring that personal protective clothing is worn by operating personnel, e.g. work clothes, safety shoes and protective gloves.

1.5 Intended use

Peltier-cooled incubators IPP are intended for the storage of substances and samples, for determination of life expectancy as well as for cultivation and incubation in a temperature range of 0 to 70 °C..

The appliance is not explosion-proof (does not comply with the German occupational health and safety regulation VBG 24). The appliance may only be loaded with materials and substances which cannot form any toxic or explosive vapours at the set temperature and which cannot explode, burst or ignite.

The appliance may not be used to dry, vaporise or brand materials for which the purchasing or its components constitutes a risk of fire and/or explosion, especially if the solvents of these materials could form an explosive mixture when combined with air. If there is any doubt as to the composition of materials, they must not be loaded into the appliance. Potentially explosive gas-air mixtures must not form, neither in the chamber nor in the direct vicinity of the appliance.

1.6 Changes and alterations

No unauthorised changes or alterations may be made to the appliance. No parts may be added or inserted which have not been approved by the manufacturer.


Unauthorised changes or alterations result in the CE declaration of conformity losing its validity, and the appliance may no longer be operated.

The manufacturer is not liable for any damage, danger or injuries that result from unauthorised changes or alterations, or from non-compliance with the provisions in this manual.

1.7 Behaviour in case of malfunctions and irregularities

The appliance may only be used in a flawless condition. If you as the operator notice irregularities, malfunctions or damage, immediately take the appliance out of service and inform your superior.

1.8 Switching off the appliance in an emergency



Press the main switch on the ControlCOCKPIT and disconnect the power plug. This disconnects the appliance from the power supply at all poles.

2. Construction and description

2.1 Design

Description	Overview - IPP110eco
1. ControlCOCKPIT with capacitive function keys and LCD displays	
2. Main switch	
3. Peltier-Element	
4. Slide-in units	
5. Inner glass door	
6. Nameplate	
7. Door-handle	
8. Turn control with confirmation key	

Description	Overview - IPP1060eco
1. ControlCOCKPIT with capacitive function keys and LCD displays	
2. Main switch	
3. Slide-in units	
4. Heated full-sight glass door	
5. Nameplate	
6. Lockable castors with extendable feet	
7. Door-handle	
8. Turn control with confirmation key	

2.2 Description

Appliance size 110 to 1060	Description
IPPeco	The appliances can heat the interior up to +70 °C and cool it down to +5 °C. Low-noise, long-life and energy-saving Peltier cooling and heating technology is used for this. In heating operation, a part of the required energy is extracted from the surroundings (heat pump principle).
Appliance size 1400 to 2200	Description
IPPeco	The appliances can heat the interior up to 70 °C and cool it down to +5 °C. Low-noise, long-life and energy-saving Peltier cooling and heating technology is used for this. In heating operation, a part of the required energy is extracted from the surroundings (heat pump principle).

2.3 Material

These appliances fulfil the current requirements of the RoHS Directive. For more information about this and about the Material Compliance of these Memmert appliances in general, please visit our homepage at www.memmert.com.

Components	Material
Housing (lid + side panel)	Stainless steel 1.4016 - ASTM 430
Housing (rear panel)	Galvanised steel plate
Interior (incl. covers)	Stainless steel 1.4301 - ASTM 304
Accessories (perforated sheet, steel grid)	Stainless steel 1.4301 - ASTM 304
Door seal	Silicone
Inner glass door	Glass



The chamber load for the appliance must be carefully checked for chemical compatibility with the materials mentioned.

2.4 Electrical equipment

- Operating voltage and current consumption: See nameplate
- Protection class I, i.e. operating insulation with PE conductor in accordance with EN 61010
- Protection type IP 20 acc. to EN 60 529
- Interference suppression acc. to EN 55011 class B

2.5 Connections and interfaces


2.5.1 Electrical connection

This appliance is intended for operation on an electrical power system with a system impedance Z_{max} at the point of transfer (service line) of a maximum of 0.292 Ohm. The operator must ensure that the appliance is operated only on an electrical power system that meets these requirements. If necessary, you can ask your local energy supply company what the system impedance is. Observe the country-specific regulations when connecting (e.g. in Germany DIN VDE 0100 with residual current circuit breaker).

2.5.2 Communication interfaces

The interfaces are intended for appliances which meet the requirements of IEC 62368-1.

Ethernet interface



Via Ethernet interface, the appliance can be connected to a network, so that programmes created with the AtmoCONTROL software can be transferred to the appliance and protocols read out.


For identification purposes, each appliance connected must have its own unique IP address. Setting the IP address is described in chapter 7.3.2.

You will find a description of how to transfer programs via Ethernet in the enclosed AtmoCONTROL manual.

The appliance can be directly connected to a computer/laptop using an optional USB to Ethernet converter.

2.6 Designation (nameplate)



The nameplate provides information about the appliance model, manufacturer and technical data. It is attached to the front of the appliance, on the right behind the door.

Description	Overview
1. Type designation	
2. Operating voltage	
3. Applicable standard	
4. Protection type	
5. CE conformity	
6. Address of manufacturer	
7. Disposal note	
8. Temperature range	
9. Connection / power ratings	
10. Appliance number	

2.7 Technical data

Appliance size				110	260	410	750	1060	1400	2200
Appliance width (D)			mm	745	824		1224		1435	2157
Appliance height (E)			mm	864	1183	1720			1905	
Appliance depth (F)			mm	555	655	655	755	1005	1005	
Depth of door lock			mm	56						
Chamber width (A)			mm	560	640		1040		1250	1972
Chamber height (B)			mm	480	800	1200			1450	
Chamber depth (C)			mm	400	500		600	850	750	
Chamber volume			mm	108	256	384	749	1060	1360	2140
Weight (including packaging)			kg	102	173	213	279	424	450	493
Power	IPPeco		W	320	600		1300			1900
Current consumption 50/60 Hz	IPPeco	100-240 V	A	1.5-3.5	2.5-6.5		5.5-13.5			8-10*
max number steel grids/ perforated sheet			unit	5	9	14			28	42
max load per steel grid/ perforated sheet			kg	20			30	20	30	
max load per appliance			kg	150	200				250	
Temperature		Adjustment range	°C	0 to +70						
		Adjustment precision	K	0.1						

* 200–240 V



2.8 Applied directives and standards

2.8.1 Declaration of conformity



You can download the EC declaration of conformity of the appliance online under www.memmert.com/de/downloads/

2.8.2 REACH regulation

Under the REACH regulation, Memmert provides the information on chemical substances in Memmert appliances online at

<https://www.memmert.com/de/reach-rohs/>

2.9 Ambient conditions

Ambient criteria	
Ambient temperature	+16 °C to +40 °C
Air humidity	10-80 % bis 31 °C 50 % bei 40 °C
Overvoltage category	II
Pollution degree	2
Altitude of installation	max. 2,000 m above sea level
Maximum mains voltage fluctuations	AC 100-240 V (+/-10 %)

- The appliance may only be used in enclosed areas and under the ambient conditions listed below
- The appliance may not be used in areas where there is a risk of explosion. The ambient air must not contain any explosive dusts, gases, vapours or gas-air mixtures. The appliance is not explosion-proof.
- Heavy dust production or aggressive vapours in the vicinity of the appliance could lead to sedimentation in the interior and, as a consequence, could result in short circuits or damage to electrical parts. For this reason, sufficient measures to prevent large clouds of dust or aggressive vapours from developing should be taken.

2.10 Scope of delivery

Standard delivery

- Power cable
- Tilt protection
- Steel grid (number depends on appliance size)
- Operating manual
- Calibration certificate

Optional accessories

- USB- Ethernet converter. This makes it possible to connect the Ethernet connection interface to the USB port of a computer/laptop.
- Reinforced steel grid with a load capacity of 60 kg (size 110 and up)

3. Delivery, Transport and Setting Up

3.1 Safety

⚠ WARNING



The appliance could fall over and seriously injure you. Never tilt the appliance. Only transport in upright position and without load (except standard accessories such as steel grids or shelves). Appliances with castors always have to be moved on level ground by at least two people.

⚠ CAUTION



Because of the heavy weight of the appliance, you could injure yourself if you try to lift it. At least four people are needed to carry appliance sizes 110 and 260. Appliances larger than that may not be carried, but must be transported using a manual pallet jack or forklift truck.

110 and 260




410 and up



⚠ CAUTION



You may get your hands or feet squashed when transporting and installing the appliance. Wear protective gloves and safety boots. Only grasp the appliance at the sides of the base:



3.2 Delivery

Appliance size 110 to 1060

- The appliance is packed in cardboard and is delivered on a wooden palette.

Appliance size 1400 to 2200

- The appliance is packaged in a wooden crate and delivered on a wooden pallet.

3.3 Transport

The appliance can be transported in three ways:

- With a forklift truck or a manual pallet jack; move the forks of the truck entirely under the pallet
- On its own castors, in case of the corresponding configuration, for which the catch on the (front) castors must be released

3.4 Unpacking

- To avoid damage, do not unpack the appliance until you reach the installation site.
- Remove the cardboard packaging by pulling it upwards or carefully cutting along an edge or unscrew and remove wooden crate

3.4.1 Checking for completeness and transport damage

- Check the delivery note to ensure that the scope of delivery is complete
- Check the appliance for damage

If you notice deviations from the delivery note, damage or irregularities, do not put the appliance into operation but inform the haulage company and the manufacturer.

3.4.2 Remove the transportation lock

- Remove the transportation lock. It is located between the door hinge, door and frame and has to be removed after opening the door.

3.5 Disposing of packaging material

- Dispose of the packaging material (cardboard, wood, foil) in accordance with the applicable disposal regulations for the respective material in your country

3.6 Storage after delivery

If the appliance is first to be stored after delivery:

- Observe storage conditions, see chapter 9.1

3.7 Setting up

WARNING



Due to its centre of gravity, the appliance can fall over to the front and injure you or other people. Always attach the appliance to a wall with the tilt protection. In case there is not enough space, do not put the appliance into operation and do not open the door. Contact the Memmert service.


3.7.1 Preconditions

The installation site must be flat and horizontal and able to reliably bear the weight of the appliance. Do not place the appliance on a flammable surface.


Depending on the model (see nameplate), a 230 V or 115 V power connection must be available at the installation site.

The distance between the wall and the rear of the appliance must be at least 15 cm. The clearance from the ceiling must not be less than 20 cm and the side clearance from walls or nearby appliances must not be less than 5 cm. Sufficient air circulation in the vicinity of the appliance must be guaranteed at all times.

For appliances with castors, these need to be positioned in forward direction at all times.




3.8 Installation options


Setting up		Comments	110	260 410	750 1060	1400 2200
Bottom			✓	✓	✓	✓
Table		Check the load capacity first	✓	✗	✗	✗
Stacked		two appliances maximum; mounting material (feet) provided	✓	✗	✗	✗
Sub frame		with/without castors	✓	✓	✗	✗
Castor frame			✓	✓	✗	✗
Height adjustable feet			✓	✓	✓	✓

3.9 Level and secure the device against rolling away (Sizes 1400 and 2200)


The height of the appliance can be adjusted using the heavy-duty castors attached to the bottom of the appliance. It can also be secured against rolling away or being shifted. To do this, the feet must be extended.



1. To unlock the adjustment mechanism, pull out the ratchet lever on the ring




2. To retract and extend the stand, actuate the ratchet lever



The direction of movement (up/down) can be adjusted using the rocker above the ratchet lever:

- Press in the rocker on the right side to extend the stand with the ratchet lever



- Press in the rocker on the left side to retract the stand with the ratchet lever

In the end position, push in the ratchet lever again to fix the stand.



Use a spirit level to ensure that all four feet are adjusted to the same height.


To move the cabinet, all four feet must be retracted.

3.10 Tilt protection

NOTICE


Two anti-tilt brackets are included with the 1400 and 2200 sizes. For a stable hold, both anti-tippers must be attached.

Attach the appliance to a wall with the tilt protection. The tilt protection is included in the scope of delivery.



1. Tighten the tilt protection onto the back of the appliance as illustrated.

i Depending on the ambient conditions, the tilt protection can be fastened to either of the two holes in the appliance.



2. Bend the tilt protection upwards by 90° in the desired distance to the wall (observe the minimum distance to the wall).
3. Drill a hole, insert a dowel and screw the tilt protection to a suitable wall.


3.11 Adjusting doors

You can adjust the doors if necessary, for example if they are warped due to uneven flooring. There are two adjusting screws each at the top and the bottom of each door for this purpose. First, adjust the setting at the top of the door and, if this is not sufficient, adjust the screws at the bottom of the door.



Door adjustment is also available as a service video:
<https://www.memmert.com/de/downloads/media/service-videos/>

1. Open the door.
2. Loosen the screws.
3. Adjust the position of the door.
4. Tighten the screws again.
5. Check the position of the door.
6. Readjust if required.



4. Putting into operation

⚠ WARNING



Condensation in the electrical components may cause short circuits. After transporting or storing the device under humid conditions, remove it from its packaging and let it ventilate for at least 24 hours in normal environmental conditions. Do not connect the device to the mains power during this time.


The device cannot be expected to meet all safety requirements of the standard DIN EN 61010-2-010:2015-05 during the drying process.

⚠ CAUTION



When putting the appliance into operation for the first time, do not leave it unattended until it has reached a steady state.

4.1 Connecting the appliance



Observe the country-specific regulations when making connections (e.g. DIN VDE 0100 with earth leakage circuit breaker, in Germany). Observe the connection and power ratings (see name plate and the "Technical Data" chapters 2.7 and 2.8). Make sure to establish a safe PE conductor connection.


Plug the provided power cable into the rear of the appliance and connect it to the power supply.

Place the power cable so that


- it is easily accessible at all times and can be pulled off quickly, for example in case of interference or an emergency
- it does not represent a trip hazard
- it cannot come into contact with any hot parts

4.1.1 Hook drip pan

Holders for the drip pan are next to each Peltier dehumidifier. The drip pan is hooked into the holders from above



4.2 Switching on



Press the main switch on the front of the appliance.

The start-up process is shown by three animated white dots . If the dots have another colour, an error has occurred (error messages see chapter 6). The appliance displays are in English by default when the appliance is switched on for the first time. How you can change the languages is described in chapter 7.2.

However, to get a basic overview of operating the appliance, you should read the following chapter first.

5. Operation and control

5.1 Operating personnel


The appliance may only be operated by persons who are of legal age and have been instructed accordingly. Personnel who are to be trained, instructed or who are undergoing general training may only work with the appliance under the continuous supervision of an experienced person.

Opening the door


WARNING



With appliances above a specific size, you could become accidentally locked inside, which could put you at risk of death. Do not climb into the appliance!



To open the door, pull the door handle sideways (to the left or to the right, depending on the door version, and open the door wide.



To close the appliance, push the door closed and push the door handle sideways.

Loading the appliance


WARNING



When loading the appliance with an unsuitable load, poisonous or explosive vapours or gases may be produced. This could cause the appliance to explode, and persons could be severely injured or poisoned. The appliance may only be loaded with materials which do not form any toxic or explosive vapours when heated up, and which cannot ignite. If there is any doubt as to the composition of materials, they must not be loaded into the appliance.

Check the chamber load for chemical compatibility with the materials of the appliance.


Insert the sliding steel grids or sliding shelves. The maximum number of grids / shelves and the load capacity are specified in the technical data overview in chapter 7.3.5. To achieve optimal temperature distribution, the type of slide-in unit used – steel grid or shelf – must be set in the menu under SETUP.



The chamber must not be loaded too tightly, so that proper air circulation in the interior is guaranteed.

Do not place any load on the floor, on the side walls or under the ceiling of the interior

In case of improper loading (not enough space between the items), the set temperature may be exceeded or it may take longer until it is reached.




(see also the “correct loading” sticker on the appliance).

5.2 Operating the appliance

5.2.1 ControlCOCKPIT

In manual mode, the desired parameters are entered in the ControlCOCKPIT on the front of the appliance. You can also make basic settings here (menu mode). Additionally, warning messages are displayed, e.g. if the temperature is exceeded. In program mode, the parameters defined, the program description, the program segment currently active and program duration remaining are displayed.


IPPeco




- | | |
|---|--|
| <ul style="list-style-type: none"> 1. Activation key for temperature setpoint adjustment 2. Setpoint and actual temperature display 3. Menu key 4. Activation key digital backwards counter with target time setting 5. Main switch 6. Digital backwards counter with target time setting | <ul style="list-style-type: none"> 7. Interior lighting display (only for models with light module) 8. Interior lighting activation key (only for models with light module) 9. Turn control for setpoint adjustment 10. Confirmation key |
|---|--|

5.2.2 Basic operation



In general, all settings are made according to the following pattern:



Activate the desired parameter (e.g. temperature). To do so, press the corresponding activation key on the left or right or the respective display. The activated display is lined in colour, the other displays are dimmed. The set value is highlighted in colour.




By turning the turn control to the left or right, adjust the set value (e.g. to 37.0 °C).



Save the set value by pressing the confirmation key. The display returns to normal and the appliance begins adjusting to the defined set value.

- Additional parameters can be set accordingly
- If no new values are entered or confirmed for approx. 30 seconds, the appliance automatically restores the former values




If you want to cancel the setting procedure, press the activation key on the left or right of the display that you want to exit. The appliance restores the former values. Only the settings that you have confirmed by pressing the confirmation key before cancelling the setting procedure are accepted.

5.3 Operating modes

5.3.1 Manual mode

As described in chapter 5.2.2, you can set the following parameters after pressing the corresponding activation key (in any sequence):

Temperature



Adjustment range depends on appliance (see name plate chapter 2.7 and technical data chapter 2.8)

Heating operation is indicated by the ↑↑↑ symbol.


Cooling is indicated by the ❄ symbol.

You can select °C or °F as the temperature unit displayed.



The minimum temperature that can be reached depends on the surrounding conditions. The devices can cool down to 20 °C below room temperature. For this purpose, the Peltier module needs sufficient ventilation

Interior lighting (only for models with light module)



Adjustment range: 0 to 100 % in steps of 1%




The interior light is only active at temperatures of up to 40°. If this temperature is exceeded, the interior light switches off automatically. The light display will then show "Temp too high".

5.3.2 Operation with digital backwards counter with target time setting, adjustable from 1 minute to 99 days



In timer operation, you can adjust the time the appliance runs at the set values. The appliance has to be in manual operating mode for this.




Up to a duration of 23 hours 59 minutes, the time is displayed in hh:mm (hours:minutes) format. For 24 hours and more, the format dd:hh (days:hours) is used. The maximum duration adjustable is 99 days 00 hours.





1. Press the activation key to the left of the timer display. The timer display is activated.



2. Turn the turn control until the desired duration is displayed – in this example 4 hours 30 minutes. The approximate end time is shown beneath, in a smaller font.



3. Press the confirmation key to confirm.




The display now shows the remaining time in a large font and the approximate end time in a smaller font beneath. The status display shows Timer active.


4. Now, as described under 5.2.2, set the individual values which you want the appliance to operate at. The set values can be changed at any time while the timer elapses. The changes are effective immediately.



In **Setup**, you can choose if the timer should run setpoint-dependent or not. This determines whether the timer should not start until a tolerance band around the set temperature is reached or if it should start right after activation. The  symbol on the timer display indicates that the timer is set to setpoint-dependent.




Once the timer has finished, the display shows 00h:00m. All functions (heating etc.) are switched off. In addition, an acoustic alarm sounds, which can be turned off by pressing the confirmation key.




To- the timer, open the timer display by pressing the activation key again and then turning the turn control to reduce the timer setting until --:-- is displayed. Press the confirmation key to confirm.

5.4 Monitoring function

5.4.1 Temperature monitoring




The monitoring temperature of the electronic temperature monitoring is measured via a separate PT100 temperature sensor in the chamber. Temperature monitoring settings are made via the ALARM display. The settings made apply to all operating modes.



If temperature monitoring has been triggered, this is indicated on the temperature display: the actual temperature is highlighted in red and a  warning symbol is shown. The type of temperature monitoring triggered (TWW in this example) is shown beneath the temperature.

The alarm is additionally signalled by an intermittent acoustic signal, which can be turned off by pressing the confirmation key. Information on what to do in this case is provided in chapter 6.

5.5 Ending operation



- Switch off active appliance functions (turn back the set values).
- Remove the chamber load
- Switch off the appliance with the main switch

6. Malfunctions, warning and error messages

DANGER




Errors requiring intervention inside the appliance may only be executed by qualified electricians. Our separate service instructions must be observed.

Do not try to rectify appliance errors yourself but contact the MEMMERT customer service department or an authorised service point.


In case of enquiries, please always specify the model and appliance number on the nameplate (see chapter 2.7).

6.1 Warning message of the monitoring function

6.1.1 Temperature monitoring

Description	Cause	Action
Temperature alarm and "TWW" are displayed 	The adjustable temperature controller (TWW) has assumed heating control.	■ Increase the difference between the monitoring and setpoint temperature – by either increasing the max value of the temperature monitoring or decreasing the setpoint temperature. ■ If the alarm continues: Contact customer service

6.1.2 Malfunctions, operating problems and appliance errors

Error description	Cause of error	Troubleshooting
Displays are dark	External power supply was interrupted	■ Check the power supply
	Miniature fuse, appliance fuse or power module faulty	■ Contact customer service
Displays cannot be activated	The appliance is in program, timer or remote control mode (mode "Write" or "Write + Alarm")	■ Wait until the end of the program or timer mode or switch off the remote control
Displays suddenly look different	Appliance is in "wrong" mode	■ Change to operating or menu mode by pressing the MENU key
Error message T:E-3 in the temperature display 	Temperature operating sensor is defective.	■ The appliance can temporarily be kept in service ■ Contact customer service as soon as possible

Error description	Cause of error	Troubleshooting
When switching on the appliance, the start animation is displayed in another colour than white 	Cyan  Not enough storage space on the SD card	■ Contact customer service
	Red  The system files could not be loaded	
	Orange  The fonts and images could not be loaded	

6.2 Power failure

In case of a power failure, the appliance operates as follows:

In manual mode

After power supply has been restored, operation is continued with the parameters set. The time and the duration of the power failure is documented in the log memory.

In timer or program mode

In case of an interruption of the power supply of less than 60 minutes, the current programme is continued from the point at which it was interrupted. For longer interruptions of the power supply, all appliance functions (heating, fan etc.) are switched off.

In remote control mode

The previous values are restored. If a program has been initiated via remote control, it is continued.

7. Menu mode

In menu mode, you can make basic settings, load programs and export protocols, as well as adjust appliance parameters.




Before changing menu settings, read the description of the respective functions on the following pages to avoid possible damage to the appliance and/or chamber load.


To enter menu mode, press the MENU key.



To exit the menu mode at any time, press the MENU key again. The appliance then returns to operating mode. Only changes accepted by pressing the confirmation key are saved.



7.1 Overview



- | | |
|--|--|
| <ul style="list-style-type: none"> 1. Language selection activation key 2. Language selection display 3. Date and time display 4. Date and time setting activation key 5. Exit menu mode and return to operating mode 6. Setup activation key (basic appliance settings) | <ul style="list-style-type: none"> 7. Setup display (appliance settings) 8. Adjustment display 9. Adjustment activation key 10. Turn control for adjustment 11. Confirmation key (accepts setting made with the turn control) |
|--|--|


7.2 Basic operation in menu mode using the example of language selection

In general, all settings in menu mode are done just like in operating mode: Activate the respective display, use the turn control for setting and press the confirmation key to accept the change. A more detailed description is provided in the following, using the example of language selection.

All other settings can be made accordingly. The settings possible are described in the following sections.




If no new values are entered or confirmed for approx. 30 seconds, the appliance automatically restores the former values




1. Activate the desired parameter (in this example the language). To do so, press the corresponding activation key on the left or right or the respective display. The activated display is enlarged.



- If you want to exit or cancel the settings, again press the activation key which you have used to activate the display. The appliance returns to the menu overview. Only the settings that you have confirmed by pressing the confirmation key before cancelling the setting procedure are accepted.



2. With the turn control, select the desired new setting, e.g. Español (Spanish).



3. Save the setting by pressing the confirmation key.



4. To return to the menu overview, press the activation key again.



You can now


- activate another menu function by pressing the corresponding activation key or
- return to operating mode by pressing the MENU key.

7.3 Setup

7.3.1 Overview

In the SETUP display, you can set the following parameters:

- the IP address and subnet mask of the appliance's Ethernet interface (for connection to a network)
- the unit on the temperature display (°C or °F, chapter 7.3.3)
- how the digital backwards counter with target time setting works (Timer Mode, chapter 5.3.2)
- The type of slide-in unit (grid or shelf, chapter 7.3.5)
- the trigger temperature of the monitoring function (Max alarm, chapter 7.3.6)
- Remote control (chapter 7.3.8)
- Gateway (see page 7.3.9)




If the SETUP menu contains more entries than can be displayed, this is indicated by the display "1/2". This means that there is a second „page“ of entries.


To display the hidden entries, use the turn control to scroll beyond the lowest entry. The page display changes to "2/2".

7.3.2 IP address and subnet mask

If you want to operate one or more appliances in a network, each appliance must have its own unique IP address for identification. By default, each appliance is delivered with the IP address 192.168.100.100.




1. Activate the SETUP display. The entry IP address is automatically highlighted.



2. Accept the selection by pressing the confirmation key. The first three digits of the IP address are automatically selected.


		3. With the turn control, set the new number, e.g. 255.
		4. Accept the selection by pressing the confirmation key. The next three digits of the IP address are automatically selected. Setting these is done according to the description above.
		5. After setting the last three digits, accept the new IP address by pressing the confirmation key. The selection returns to the overview. The subnet mask is set accordingly.

7.3.3 Unit




Here, you can choose whether the temperature is displayed in °C or °F.

7.3.4 Timer mode




Here, you can choose whether the digital backwards counter with target time setting (timer, chapter 5.3.2) should run setpoint-dependent or not – this determines whether the timer should not start until a tolerance band of ± 3 K around the set temperature is reached (B) or whether it should start right after activation (A).



7.3.5 Slide-in unit type steel grid or shelf

Type of slide-in unit (steel grid or shelf)




Here, you have to select the type of slide-in unit (steel grid or shelf) used. The selection Shelf enables you to adjust the control function to the different air flow characteristics in the interior when using optional sliding shelves instead of the steel grids that are provided as standard.

7.3.6 Temperature monitoring

Here, you can set the trigger temperature of the automatic temperature monitoring system




The monitoring temperature must be set sufficiently high above the maximum set temperature. We recommend 1 to 3 K.




7.3.7 Remote control

In the setup entry remote control, you can set whether the appliance should be controlled via remote control and, if so, in which mode. These settings are available:




- Off
- Read Only
- Write + Read
- Write + Alarm



If the appliance is in remote control mode, the  symbol appears in the temperature display. In the settings Write + Read and Write + Alarm, the appliance cannot be controlled at the ControlCOCKPIT until the remote control has been switched off (setting Off) or set to Read.

In order to use the remote control function, programming skills and special libraries are required.

7.3.8 Gateway




The setup entry gateway is used to connect two networks with different protocols. The gateway is set the same way as the IP address (chapter 7.3.2).

7.4 Date and Time


In the TIME display, you can set the date and time, time zone and daylight saving time. Changes can only be made in manual operating mode.




Always set the time zone (and daylight saving time yes/no) before setting the date and time. Avoid changing the set time after that since this can lead to gaps or overlapping when recording measured values. If you still need to change the time, you should not run a program immediately before or after doing so.




1. Activate the time setting. To do so, press the activation key on the right side of the TIME display. The display is enlarged and the first adjustment option (Date) automatically highlighted.



2. Turn the turn control until Time zone is highlighted.




3. Accept the selection by pressing the confirmation key.




4. Use the turn control to adjust the time zone on the appliance location,
 - e.g. 00:00 for Great Britain
 - 01:00 for France, Spain or Germany


Accept the selection by pressing the confirmation key.



5. With the turn control, select the Daylight Savings entry.




6. Accept the selection by pressing the confirmation key. The adjustment options are highlighted.



7. Set daylight savings to off (x) or on (✓) with the turn control – in this case on (✓). Save the setting by pressing the confirmation key.



Daylight saving time and standard time are not changed automatically. For this reason, please keep in mind to adjust them at the beginning of each period.



8. Now, set date (day, month year) and time (hours, minutes) in the same way. Accept each selection by pressing the confirmation key.

7.5 Calibration

To guarantee perfect control, we recommend calibrating the appliance once a year.


7.5.1 Temperature adjustment

The appliances are temperature calibrated and adjusted at the factory. In case readjustment should be necessary later on – for example due to influence of the chamber load – the appliance can be calibrated customer-specifically using three calibration temperatures of your choice:


- Cal1 Temperature calibration at low temperature
- Cal2 Temperature calibration at medium temperature
- Cal3 Temperature calibration at high temperature

i


For temperature adjustment, you will need a calibrated reference measuring device.



Example: Temperature deviation at 30°C is to be corrected



1. Press the activation key to the right of the CALIB display. The display is enlarged and the temperature adjustment option is automatically selected.




2. Press the confirmation key repeatedly, until the calibration temperature Cal2 is selected.

Example: Temperature deviation at 30 °C is to be corrected



Temperature Cal1 5.0 c -0,2 K
Cal2 30.0 c +0,1 K
Cal3 40.0 c -0,2 K

3. With the turn control, set the calibration temperature Cal2 to 30 °C.




Temperature Cal1 5.0 c -0,2 K
Cal2 30.0 c +0,1 K
Cal3 40.0 c -0,2 K

4. Save the setting by pressing the confirmation key. The corresponding calibration value is automatically highlighted.




Temperature Cal1 5.0 c -0,2 K
Cal2 30.0 c 0,0 K
Cal3 40.0 c -0,2 K

5. Set the calibration value to 0.0 K and accept the setting by pressing the confirmation key.




TEMP 21.4 °C
Set 30.0 °C

6. Position the sensor of a calibrated reference instrument centrally in the appliance's working chamber.
7. Close the door and, in manual mode, adjust the set temperature to 30 °C.




TEMP 30.0 °C
Set 30.0 °C

8. Wait until the appliance reaches the set temperature and displays 30 °C. The reference instrument displays for example 31.6 °C.



Temperature Cal1 5.0 c -0,2 K
Cal2 30.0 c +1,6 K
Cal3 40.0 c -0,2 K

9. In the SETUP, adjust the calibration value Cal2 to +1.6 K (actual value measured minus setpoint temperature) and save the setting by pressing the confirmation key.



TEMP 30.0 °C
Set 30.0 °C

10. After the calibration procedure, the temperature measured by the reference instrument should now also be 30 °C.

With Cal1, a calibration temperature below Cal2 can be programmed accordingly, and with Cal3, a temperature above. The minimum difference between the Cal values is 10 K.

If all calibration values are set to 0.0 K, the factory calibration settings are restored.

8. Maintenance and Servicing

DANGER



Danger due to electric shock.

Penetration of liquid into the appliance can cause electric shocks and short circuits.

- **Protect the appliance from splashing water.**
- **Switch off the appliance and disconnect the mains plug before cleaning and maintenance work.**
- **The appliance must not be cleaned and disinfected wet. Allow the appliance to dry completely before putting it back into operation.**

WARNING



With appliances above a specific size, you could become accidentally locked inside, which could put you at risk of death. Do not climb into the appliance!

CAUTION



Danger of cuts due to sharp edges.

Always wear gloves when working in the interior of the chamber.

8.1 Cleaning

8.1.1 Interior and metal surfaces

Regular cleaning of the easy-to-clean interior prevents build up of material remains that could impair the appearance and functionality of the stainless steel chamber over time.

The metal surfaces of the appliance can be cleaned with normal stainless steel cleaning agents. Make sure that no rusty objects come into contact with the interior or with the stainless steel housing. Rust deposits can lead to an infection of the stainless steel. If rust spots should appear on the surface of the interior due to impurities, the affected area must be immediately cleaned and polished.

8.1.2 Plastic parts

Do not clean the ControlCOCKPIT and other plastic parts of the appliance with caustic or solvent-based cleaning agents.

8.1.3 Glass surfaces

Glass surfaces can be cleaned with a commercially available glass cleaner.

8.1.4 Peltier cooling modules

In order to guarantee perfect function and long lifetime of the Peltier cooling modules, it is absolutely essential that you remove dust deposits from the heat sink on the rear of the appliance (with a vacuum cleaner, paintbrush or bottle brush, depending on the amount).

8.2 Decontamination

CAUTION



Skin and eye contact with decontaminants may cause irritation of the hands and eyes or allergic reactions and chemical burns.

- **Wear chemical-resistant gloves during decontamination.**
- **For correct application, follow the instructions for use on the respective container of the decontamination agent**

Memmert appliances can become contaminated by loading infectious substances or by environmental influences at the place of installation. All parts of the affected appliance must be decontaminated both before sending to our service and before disposing of the appliance.

- For decontamination, we recommend commercially available decontaminants based on isopropanol or ethanol.

If you have any questions about using a decontamination agent for decontaminating Memmert appliances, please contact our service department.

After cleaning and decontamination, ventilate the installation site and allow the appliance to dry completely.

8.3 Regular maintenance

Once a year, grease the moving parts of the doors (hinges and lock) with thin silicone grease and check that the hinge screws are not loose.

To guarantee perfect control, we recommend calibrating (chapter 7.5) the appliance once a year.

8.4 Repairs and service

DANGER



**Before removing any covers, disconnect the power plug.
Work inside the device may only be carried out by qualified electricians**



Repairs and service work are described in a separate service manual.

9. Storage and disposal


9.1 Storage

The appliance may only be stored under the following conditions:

- in a dry and enclosed, dust-free room
- frost-free
- disconnected from the power supply

Before storage, remove water tube and empty the water tank (chapter 4.1.1).


9.2 Disposal



This product is subject to Directive 2012/19/EC on Waste Electrical and Electronic Equipment (WEEE) of the European Parliament and of the Council of Ministers. This appliance was placed on the market after 13 August 2005 in countries which have already integrated this Directive into their national laws. It may not be disposed of in normal household waste. For disposal, please contact your dealer or the manufacturer. Any appliances that are infected, infectious or contaminated with materials hazardous to health are excluded from return. Please also observe all other regulations applicable in this context.

Before disposing of the appliance, please render the door locking mechanism unusable, for example to prevent playing children from being locked inside the appliance.

There is a lithium battery in the ControlCOCKPIT of the appliance. Remove it and dispose of it in accordance with the regulations in your country.



- **Note for Germany:**
The appliance may not be left at public or communal recycling or collection points

Peltier cooled incubator IPPeco

Operating manual
D49033 Last updated 08/2021
English